

# Firmware crisis recovery

Date of Create: 2019/08/08

ELITEGROUP COMPUTER SYSTEMS CO., LTD.

# Firmware crisis recovery

## ➤ Crisis recovery:

1. Prepare an USB key. (Format to FAT or FAT32 type first.)
2. Unzip the BIOS file. Copy [AMI GLK SPI 8mb.bin](#) to root directory of the USB key and rename [EH20GM.BIN](#).
3. Insert the USB key to the USB port.
4. Turn off the system. Skip this step if the system is already power off.
5. Plug-in an adapter and hold the both key [<Fn>](#) and [<R>](#) in internal keyboard.
6. Power-on the system by power button.
7. The system will enter crisis mode and recovery BIOS automatically.