

General Enable Application Optimized Routing

Save

 Enable Bandwidth Based Balance Routing

Help

Select Bandwidth Based Balance Routing ports:

 WAN1 WAN2**Note:**

1. To make "Bandwidth Based Balance Routing" take effect, please first configure WAN bandwidth on "Network" > "WAN" page.
2. The WAN port traffic ratio will be equal to the preset bandwidth ratio of each WAN port after "Bandwidth Based Balance Routing" of the port is enabled.
3. If the bandwidth ratio of WAN1 and WAN2 is set as 2:1, the traffic ratio of WAN1 and WAN2 will approximate 2:1 after "Bandwidth Based Balance Routing" of WAN1 and WAN2 is enabled.
4. "Bandwidth Based Balance Routing" cannot be applied to L2TP/PPTP VPN and the secondary connection of dual-access.