


3.4.8 AMD PBS



AMD Firmware Version

Press [Enter] to view information of all AMD Firmware versions.

Graphics Features

Press [Enter] to configure Graphics Features - HG, DGPU Features, and BOMACO.

Primary Video Adaptor

Allows you to select Internal/External Graphics. Default setting is [Int Graphics (IGD)].

Configuration options: [Int Graphics (IGD)] [Ext Graphics (PEG)]

AMD Common Platform Module

Press [Enter] to configure AMB Common Platform Module options. BIOS procedure library is designed to aid AMD customers to quickly implement AMD platform technology into their products.

PCIe/GFX Lane Configuration

Allows you to configure J10 Slot PCIe Lanes.

Configuration options: [Auto] [x8x8] [x8x4x4] [x4x4x4x4]